



Installing MotionTools® 3 Software

1. **Download Your MotionTools 3 Software** (<http://www.gyration.com/downloads>)
Windows® Version (*MotionTools-3-Windows.zip*)
OS X® Version (*MotionTools-3-OSX.zip*')
2. **Check Your Computer Operating System**
(*MotionTools 3 requires the 64-bit version of Windows or OS X*)
3. **De-Install earlier version(s) of MotionTools already installed?**
(*Your existing customized screen effects and mouse settings will not be saved*)
- 4.. **Install MotionTools 3**

Windows Version

1. Double-click the .zip' file to extract *MotionTools-Version-3-Windows.exe*.
2. Move the *MotionTools-Version-3-Windows.exe* to your desired application folder.
3. Double-click to run MotionTools 3.

OS X Version

1. Click the downloaded '.zip' file to extract the *MotionTools.app* file.
2. Move the *MotionTools.app* to your Application folder.
3. Click the *MotionTools.app* icon to start MotionTools 3.

5. Test MotionTools 3 Installation with your Air Mouse®

1. Cursor control (desktop and hand-held 'in air' mouse operation)
2. Air Mouse button assignments and hand-gesture controls
3. Voice activated presentation and screen effects (*Air Mouse Voice only*).

Should Questions Arise
Contact Gyration Product Support
(888) 340-0033
(gsupport@smkusa.com)